

BORO



AGRO 7265

Kapellbyggnation Mounting Instructions

A - Screws, nuts and washes supplied (plastic bag) (for check up)

1 - Separate sets



2 - Complete package



B - Assembly of the 4 Corners Bars

1. Corners bars (as supplied); place each corner bar exactly as shown on the (right) illustration, inserting their bottom, vertically, into the corresponding hole of the original Agro panel.



C - Horizontal assembly of the 2x2 medium Side Bars + 1 front Bar

1. Place and screw the medium side bars as shown on the illustration below.



D - Vertical Assembly of the 3 Roof Bars

1. Place and screw the roof bars as shown on the illustration below.



E - Horizontal Assembly of the 2x3 Roof Bars

1. Place and screw the roof bars as shown on the left illustration below.
2. Secure the roof with the special screws, as shown on the right illustration below.



F - Tarpaulin

1. Place and attach securely the tarpaulin.
2. Enjoy your improved trailer.

